

Montageanleitung / Mounting instruction *Chrome Design parts*
Mercedes Benz SLK Class R 171

Grill-Lamellen-Leisten 12 teilig verchromt



1. Vor dem Anbringen der Teile, diese auf ihre Vollständigkeit und Passform überprüfen.
2. Wenn alles in Ordnung ist, reinigen Sie den Klebepbereich am Fahrzeug gründlich.

Wichtiger Hinweis:

Es ist darauf zu achten, dass die Teile nur bei einer Temperatur (auch Fahrzeugtemperatur) von mindestens +20°C angebracht werden dürfen.

3. Die Chromleisten sind bereits mit einem doppelseitigen Klebeband versehen.
4. Entfernen Sie den Schutzfilm des doppelseitigen Klebebandes.
5. Platzieren Sie die Chromleisten auf die jeweilige Lamelle und prüfen Sie die Passgenauigkeit.
6. Bei korrektem Sitz drücken Sie die Chrom-Leiste kräftig an. Versuchen Sie dies mit einem gleichmäßigen Druck auf der gesamten Fläche.
7. Die Chromleiste ist jetzt in ihrer endgültigen Position.
8. Die Endklebefestigkeit der Klebestreifen wird nach ca. 36-48 Stunden erreicht. Tragen Sie dafür Sorge, dass die Leiste in diesem Zeitraum unberührt bleibt.

Wichtiger Hinweis:

Bitte grundsätzlich keine Hochdruckreinigung vornehmen!
Dies gilt auch für die Vorreinigung in Waschstrassen!!!
Die Verklebung ist erst nach 48 Stunden Waschanlagenfest.

Grill trim strips chrome covered 12 pieces

1. Before applying, inspect the parts for damages and check that all parts are complete.
2. Be sure that the whole area of the car is totally cleaned up, where you will fasten the parts.

Important Information:

Moreover, it must be noted, that the chromium parts may only be applied with least minimum temperature (incl. automobile) of at least +20°C.

3. The grill trim strips chrome is already equipped with double sided tape.
4. Remove the protective liner from the double sided tape stripes
5. Place each piece in its correct position and proof the fitting correctness.
6. After checking the correct positioning, apply a vigorous pressure on the chromed piece with both hands, trying to push with uniformity on the surface.
7. The fitting is completed.
8. Definitive drying of the double sided tape will succeed after 36-48 hours.
9. Consequently it is suggested not to pull the part backwards within these terms.

Important Information:

Never clean using high pressure!

This also applies to precleaning in car washes!!!

The vehicle should not be cleaned in the car wash until 48 hours have elapsed.