

This installation manual is for RHD (Right-Hand Drive) SL R230 convertibles only.

Installation RHD SL - Steps 1-3



1. For general information about connecting the module, please refer to the main installation and operation manual. **This installation manual is for RHD (Right-Hand Drive) SL convertibles only.** Open the luggage compartment behind the driver's seat.




2. Take out the bottom lid as shown.




3. Locate the thick red wire with a green stripe. This is the +12V power wire used for the module. Find ground on one of the brown wires close by or strip the brown wire from the module's harness and get ground from one of the chassis bolts.


Installation RHD SL - Steps 4-6



4. The CAN connector is on the left side, snapped into a metal bracket. Remove it from the bracket and remove the plastic clip as described in the main manual.



5. Connect the module to the 5th plug from the right (marked in the picture).



6. Overview of the installation. Check if the LED on the module blinks when you hit the UNLOCK button on the remote. If it doesn't, you will need to try all the CAN connectors until you find the correct one.